

ORION

GRID CONNECT

SMART OUTDOOR SECURITY CAMERA



**AUTOMATICALLY
DETECTS &
TRACKS MOTION**

**SEE & RECORD EVERYTHING
THAT HAPPENS USING YOUR
SMARTPHONE**

QUICK START GUIDE

IMPORTANT!
PLEASE READ THESE
INSTRUCTIONS CAREFULLY



SC065WHA

1 INTRODUCTION

This SMART outdoor security camera is designed for use in homes, apartments, offices, garages and sheds. It has been developed to be easily set up and operated, giving you and your family the security and peace of mind that you deserve.

Install the Grid Connect mobile app, available for both iPhone and Android devices, to monitor your camera remotely.

The Grid Connect app is free to download and is available from the Apple App Store and Google Play.

MONITOR FROM ANYWHERE



DOWNLOAD PAIR USE

Download from:



GET IT ON Google Play
Download on the App Store

2 CONTENTS

- 1 x Smart Outdoor Security Camera
- 1 x Power Adaptor
- 1 x Mounting Stand
- 3 x Mounting Screws & Wall Plugs
- 1 x L Shape Screw Driver
- 2 x Deterrent Stickers
- 1 x Drill Template



Micro SD Card 16GB
Class 10 required
(Max. 128GB card supported)

3 IDENTIFICATION

Antenna

Microphone

Infrared LEDs

Allow camera capture both day and night image

Camera Lens

1080p HD, with 125° field of view

Status Light

Micro SD Card Slot

Use a micro SD memory card to record video.


Reset Button

Press and hold for 5 seconds to reboot and clear all settings to factory defaults. This will allow you to connect with different Wi-Fi network if required.


Speaker

Power Cable

Low volatge 12V



4 DOWNLOAD THE APP



NEW ACCOUNT
LOG IN SETUP

Download and install
GRID CONNECT App
from Play store (Android)
or App store (iOS).



Scan & download
the GRID Connect
App for free

5 INSTALL THE APP



Open the  **GRID CONNECT** App. If you are a new user, tap *create new account* and follow the prompts to complete account setup.


create new account

Note: You must agree with the Privacy Policy to be able to use the App.

If you already have an existing account, just tap login to account and enter your login details to continue.

login to account

6.0 PAIRING YOUR DEVICE




Power on your smart camera by using the supplied adaptor.

It should take approximately 10 seconds to startup and will indicate as such with a solid red light.

You will hear a welcome sound. Confirm the status light is red and rapidly blinking (approximately 2 times per second). The camera is now ready for pairing.

Once your camera is in pairing mode, open the GRID CONNECT App, Tap , then select **security** in **add device** page. Confirm the status light is red and rapidly blinking (approximately 2 times per second) before tapping **ready to pair** to proceed.

6.1 PAIRING YOUR DEVICE




confirm

Enter the Wi-Fi password and tap **confirm** to proceed.

If needed, you can tap **change network** to switch to another suitable Wi-Fi network for your camera.

6.2 PAIRING YOUR DEVICE




Press **continue** to scan QR code using your camera. Hold 15cm away from your mobile screen.

Press **heard the beep** after you hear a sound from your camera. The status light should be blue, and blinking (refer to trouble shooting guide on page 20 if you don't hear the prescribed beep).

The GRID CONNECT App will start to connect to the camera automatically as indicated by the status light being solid blue.

6.3 PAIRING YOUR DEVICE



Once the pairing process is complete a page showing **device added successfully** will appear.

You may choose to edit the device name or assign the device to a dedicated room before tapping **done** to finish the pairing process.

Once your camera is paired to your Wi-Fi network, your camera can be viewed at anytime from your smartphone as long as there is internet access.



If no device is found and the pairing process is not successful, check below and repeat from Step 6

- 1 Wi-Fi network is 2.4GHz.
- 2 Wi-Fi password entered is correct and the same Wi-Fi network is used on the mobile device.
- 3 GRID device is in pairing mode.
- 4 Check your Wi-Fi for network activity.


7 OPERATING YOUR CAMERA

Once your camera is paired to your Wi-Fi network, you can view your camera at anytime from your smartphone as long as there is internet access.

Live Screen

Back to Device Screen

Switch video quality between Standard definition (smoother movement with smaller file size) and High definition (clearer images but larger file size)



Access Settings including share device, motion detection setting, firmware information, remove device etc.

Switch to full screen display for live view

Playback Screen

Pause video playback

Slide forward/back video playback on time slider



Feature Controls



Tap to capture a photo/video during live view. Note: the photo and video are saved to the internal memory of your smartphone



Tap to enable the talk function



Access live screen



Enable sound & motion detection alerts and adjust sensitivity of sound & motion detection



Tap to mute or hear the sound

Feature Controls



Tap to capture a photo/video during playback. Note: the photo and video are saved to the internal memory of your smartphone



Tap to mute or hear the sound



Select a date to review your playback from SD card



Access to SD card setting



Access playback screen

For more advanced features/functions, refer to grid-connect.com.au for more details

8 INSTALLATION

PREPARATION


Pair your camera inside the house before installation. Before choosing your preferred location, check the Wi-Fi strength/coverage to ensure the camera is fully functional.

Note: For ceiling/under eave, ensure you navigate to **settings > basic function settings > flip screen** to obtain correct orientation.

UNDER EAVE MOUNT


The camera can be mounted using the screws and wall plugs provided.

1. Position 12V d.c. power adaptor to a socket outlet as close to your mounting location as possible. Plan the route of the cable from your socket outlet and the camera.
(Note: The power adaptor and its cable must be kept under eave).
2. Use the mounting base or provided drill template to mark the screw positions under your eave. Take into consideration where you'll have the best view. Drill holes into the eave and push wall plugs into the holes.
3. Use the screws to secure the camera in place.



POSITIONING THE CAMERA

1. Loosen the lock screw to adjust the camera's orientation. Make adjustment with the help of the GRID APP until you get the desired live view.
2. Tighten the lock screw to secure in place by provided 'L Shape' screw driver.



9 TROUBLE SHOOTING

<p><i>What can I do if I fail to pair my GRID Connect device?</i></p>	<ol style="list-style-type: none"> 1. Check your mobile device is connected to a 2.4GHz Wi-Fi network, refer to below question for how to check Wi-Fi network frequency 2. Check password entered is correct and the same Wi-Fi network is used on the mobile device as the device being paired 3. Check GRID device is in pairing mode, the status light is red and rapidly blinking (approx 2 times per second). 4. Check the internet connection on your Wi-Fi network by browsing any website <p>If your problem persists, please refer to GRID website or contact Customer Service team (detail below) for further assistance</p>	<p><i>Do our current GRID products support 5GHz wireless connections?</i></p>	<p>No - GRID products currently do not support 5GHz wireless connection</p>
<p><i>How can I find out whether my network is 2.4GHz?</i></p>	<p>For iPhone User</p> <ol style="list-style-type: none"> 1. Navigate the Settings menu and click on Wi-Fi. The suffix of your network may be denoted by either a 2.4G or 5G 2. If you are having trouble finding out if you are on a 2.4GHz Wi-Fi network, it will be necessary to check your router specifications. For more information on this process, please consult your specific router's manufacturer or user manual for more details <p>For Android User</p> <ol style="list-style-type: none"> 1. Navigate the Settings menu and click on Wi-Fi 2. Tap the connected Wi-Fi network and the system will show the Wi-Fi Frequency 	<p><i>If I forget my GRID Connect app account password, how can I reset my password?</i></p>	<p>If you forget your password, you can tap forgot password and enter your GRID Connect registered account details to get a verification code and reset your password</p>
<p><i>What can I do if I cannot scan the QR code or don't hear the prescribed beep</i></p>	<ol style="list-style-type: none"> 1. Ensure the status light is red and rapidly blinking (approx 2 times per second) before scanning QR code 2. Ensure your Wi-Fi network is correct by checking the above sections 3. Ensure to keep your smart phone 15cm to 20cm away from your camera 4. It may take several seconds to scan QR code 	<p><i>When pairing, should my GRID device or mobile phone be in same room with Wi-Fi router?</i></p> <p><i>I want to pair my camera and it isn't in pairing mode, how do I put it into pairing mode?</i></p>	<p>No - they do not need to be in the same room, but it is recommended to pair the GRID device as close to the router as possible to assist with a successful pair</p> <p>Use the reset pin to press and hold the reset button for 5 seconds. The status light should now be red and blinking rapidly to indicate it is ready for pairing</p>

For further Online Assistance or Customer Service Team

 grid-connect.com.au

 **1300 267 168**
(toll free)

• WARRANTY

Arlec guarantees this product in accordance with the Australian Consumer Law and all other applicable Australian and New Zealand laws that are unable to be excluded.

Arlec also warrants to the original first purchaser of this product ("you") from a retailer with which this document is given that this product will be free of defects in materials and workmanship for a period of 12 months from the date of purchase; provided the product is not used other than for the purpose, or in a manner not within the scope of the recommendations and limitations, specified by Arlec, is new and not damaged at the time of purchase, has been maintained in accordance with the recommendations specified by Arlec, has not been subjected to abuse, misuse, neglect or damage, has not been modified or repaired without the approval of Arlec and has not been used for commercial purposes ("Warranty").

If you wish to claim on the Warranty, you must, at your own expense, return the product, and provide proof of original purchase and your name, address and telephone number, to Arlec at the address below or the retailer from whom you originally purchased the product within 12 months from the date of purchase.

Arlec will (or authorise the retailer to) assess any claim you may make on the Warranty in the above manner and if, in Arlec's reasonable opinion, the Warranty applies, Arlec will at its own option and expense (or authorise the retailer to) replace the product with the same or similar product or repair the product and return it to you or refund the price you paid for the product. Arlec will bear its own expenses of doing those things, and you must bear any other expenses of claiming on the Warranty.

For goods purchased in Australia (only):

The Warranty is in addition to other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For goods purchased in New Zealand (only):

The Warranty is in addition to, and does not affect, other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods come with guarantees that can only be excluded under the New Zealand Consumer Guarantees Act 1993 to the extent you are acquiring the product for a business purpose and it would be fair and reasonable for Arlec to contract out of those guarantees.

Arlec Australia Pty. Ltd. ACN 009 322 105 gives the Warranty for goods purchased from a retailer in Australia by you and Arlec New Zealand Limited NZBN 9429030738294 gives the Warranty for goods purchased from a retailer in New Zealand by you (collectively Arlec).

Arlec's telephone number, address and email address for purposes of giving the Warranty are:

Telephone Number:

1800 826 859 (in Australia) • 0800 003 329 (in New Zealand)

Street Address:

Building 3, 31-41 Joseph Street, Blackburn North, Victoria, 3130, Australia

Postal Address:

Blackburn North LPO, P.O. Box 1065, Blackburn North, 3130, Australia

Email: cs@arlec.com.au

ORION